

336 Excavator Checklist

DATE:	UNIT #				
HOUR	METER: INSPECTION COMPLETED BY:				
	As Required				
	Check and adjust track sag				
	Check washer fluid level				
	Check and adjust air conditioner belt				
	Check and clean air cleaner dust unloader valve				
	Check and clean radiator air inlet screen				
	Clean radiator core and oil cooler				
	Clean fuel tank inlet screen				
	Drain water and sediment from fuel tank sump				
	Add coolant extender as indicated by COOL-GARD™ II test strips				
	Drain water and sediment from primary fuel filter and water separator				
	Every 10 Hours or Daily				
	Check engine oil level/System - grease & inspect				
	Check hydraulic tank oil level/System - Mulcher Head (cracks/leaks)				
	Check engine coolant level/System				
	Check bucket teeth - check under carriage				
	Check seat belt				
	Inspect and re-torque track hardware				
	Fire Extinguisher (Charged)				
	First Aid Kit				
	Spill Kit				
	Every 100 Hours				
	Lubricate bucket and link pins				
	Lubricate working pivots				
	Lubricate front end pin joints				
	Every 250 Hours				
	Lubricate blade pins				
	Inspect and re-torque track hardware				
	Drain water and sediment from hydraulic tank				
	Check travel gear case oil level				
	Check battery electrolyte level and terminals				
	Take engine oil sample				
	Every 500 Hours				
	Drain and refill engine oil and replace filters				
	Lubricate swing bearing gear				
	Lubricate swing bearing Lubricate control lever universal joint				
	Lubricate control lever universal joint Check radiator coolant level				
	Check air intake hose Clean sab fresh air and sab resingulation air filters (replace every 6 cleanings)				
	Clean cab fresh air and cab recirculation air filters (replace every 6 cleanings)				
	Replace primary fuel filter and water separator				

]	Replace final fuel filter
	Take diesel fuel sample
	Take hydraulic oil sample
	Take engine coolant sample
ľ	Take travel gear case oil sample

	Every 1000 Hours
Replace hydraulic tank oil filter	
Replace pilot system oil filter	
Replace engine air cleaner element	
Check and adjust fan belt tension	
Check and adjust engine valve lash	
Check starter and alternator	
	Every 2000 Hours
Clean engine crankcase ventilation tube	
Drain and refill travel gear case oil	
	Every 3000 Hours
Service exhaust filter	
	Every 4000 Hours
Replace Swing drain filter	
	Every 5000 Hours
Drain and refill hydraulic tank oil	

MULCHER HEAD → Teeth torqued DAILY
→ Inspect drive belt, pully bolts & torque screws behind pully every 40 hours

NOTES:				